

5-24-2016

Spouted bed design considerations for coated nuclear fuel particles

Douglas W. Marshall

*Fuel Design and Development, Battelle Energy Alliance, LLC, Idaho Nuclear Laboratory, Idaho Falls, Idaho, USA.,
douglas.marshall@inl.gov*

Follow this and additional works at: http://dc.engconfintl.org/fluidization_xv



Part of the [Chemical Engineering Commons](#)

Recommended Citation

Douglas W. Marshall, "Spouted bed design considerations for coated nuclear fuel particles" in "Fluidization XV", Jamal Chaouki, Ecole Polytechnique de Montreal, Canada Franco Berruti, Wewstern University, Canada Xiaotao Bi, UBC, Canada Ray Cocco, PSRI Inc. USA Eds, ECI Symposium Series, (2016). http://dc.engconfintl.org/fluidization_xv/102

This Abstract and Presentation is brought to you for free and open access by the Proceedings at ECI Digital Archives. It has been accepted for inclusion in Fluidization XV by an authorized administrator of ECI Digital Archives. For more information, please contact franco@bepress.com.

Spouted Bed Design Considerations for Coated Nuclear Fuel Particles

Douglas W. Marshall, Technical Lead

**Fuel Design and Development
Battelle Energy Alliance, LLC
Idaho National Laboratory**

May 22 - 27, 2016

www.inl.gov




Outline

- Background
- Design considerations
- Nuclear fuel particle CVD furnace design
 - Converging section
 - Gas injector nozzle
 - Gas paths

Background Information

- High Temperature Gas-cooled Reactor (HTGR)
 - Graphite moderated, helium cooled reactor ($750^{\circ}\text{C} \leq T_{\text{exit}} \leq 900^{\circ}\text{C}$)
 - Fuel kernels $425\ \mu\text{m} - 500\ \mu\text{m}$; $10.8 - 11.2\ \text{g}/\text{cm}^3$
 - Kernels hermetically sealed in 4 coating layers (TRISO particle)
 - Layers form the primary containment for fission products




Design Considerations

- Nuclear criticality safety (geometrically safe)
 - ~~Fissile material mass~~
 - Fissile material geometry
 - Neutron moderation, ~~reflection~~, and ~~absorption~~
- Depositions take place at 1230°C – 1580°C
- No internal instrumentation
 - Limited material selection
 - Chemical contamination of product
 - Mechanical damage to nascent layers
 - Freeboard gas opacity and bed luminance

Design Considerations

- Geldart Group B particles
 - Spoutable as shallow bed
 - Dynamic bed properties
 - Density (11 → 3 g/cm³)
 - Diameter (425 → 870 μm)
 - Bed expands 8-fold
- Fluidized by hydrogen, argon, and precursor gases
 - Gases enter cold
 - Exothermic decomposition



Design Considerations

- High particle integrity needed
 - Uniform layer thicknesses and densities
 - Highly isotropic pyrocarbon
 - High density silicon carbide
- Low reject fraction required
 - Minimize radioactive waste and fissile material recycle
 - High productivity
- No “dead” zones in the bed
- Uniform bed temperature profile
- Uniform particle residence times in the annulus

Design Considerations

- “Blind” process (no internal instrumentation)
 - Pressure instruments on gas lines verify bed movement
 - Modeling of instantaneous conditions with CPFDParracuda VR software


CVD Furnace Design

- Nuclear-grade graphite retort (15.2 cm ID)
- Converging section uniquely shaped
 - Narrow included angle at top (22°)
 - Promotes mass flow
 - Precludes dead zones
 - Wide included angle at bottom (116°)
 - Encourages spout stability
 - Prevents bulk bed levitation
 - Prevents gas impingement on walls
 - Accommodates gas distributor nozzle




CVD Furnace Design

- Multiport gas distributor (graphite)
 - High gas flow without excessive penetration
 - Broader active coating zone
 - Domed to shed particles
- Annular gas orifice
 - Flanged rim
 - Reduced heat transfer
 - Offset for annular gap
 - Inert “auxiliary” gas around perimeter
 - Fluidizes bed at the bottom
 - Displaces reactive coating gases
 - Cools nozzle-retort interface



Results

- 2000 grams of uranium kernels per charge
- 160 coating runs accomplished
- Coating batches routinely meet fuel specifications
- Improved sphericity relative to lab-scale coater



Questions?

Douglas Marshall

douglas.marshall@inl.gov

Idaho National Laboratory

+1 (208) 526-3657

