

5-24-2016

High-efficiency mixing of fine powders via sound assisted fluidized bed for metal foam production by an innovative cold gas dynamic spray deposition method

Ammendola P

Istituto di Ricerche sulla Combustione – CNR, Italy, paola.ammendola@irc.cnr.it

Raganati F

Istituto di Ricerche sulla Combustione – CNR, Italy

Scherillo F

Istituto di Ricerche sulla Combustione – CNR, Italy

Squillace A

Istituto di Ricerche sulla Combustione – CNR, Italy

Chirone R

Istituto di Ricerche sulla Combustione – CNR, Italy

See next page for additional authors

Follow this and additional works at: http://dc.engconfintl.org/fluidization_xv

 Part of the [Chemical Engineering Commons](#)

Recommended Citation

Ammendola P, Raganati F, Scherillo F, Squillace A, Chirone R, Carrino L, Astarita A, and Viscusi A, "High-efficiency mixing of fine powders via sound assisted fluidized bed for metal foam production by an innovative cold gas dynamic spray deposition method" in "Fluidization XV", Jamal Chaouki, Ecole Polytechnique de Montreal, Canada Franco Berruti, Wewstern University, Canada Xiaotao Bi, UBC, Canada Ray Cocco, PSRI Inc. USA Eds, ECI Symposium Series, (2016). http://dc.engconfintl.org/fluidization_xv/106

This Abstract and Presentation is brought to you for free and open access by the Proceedings at ECI Digital Archives. It has been accepted for inclusion in Fluidization XV by an authorized administrator of ECI Digital Archives. For more information, please contact franco@bepress.com.

Authors

Ammendola P, Raganati F, Scherillo F, Squillace A, Chirone R, Carrino L, Astarita A, and Viscusi A


AN INNOVATIVE METHOD TO PRODUCE METAL FOAM USING COLD GAS DYNAMIC SPRAY PROCESS ASSISTED BY FLUIDIZED BED MIXING OF PRECURSORS

Ammendola P.^a, Astarita A.^b, Raganati F.^a, Scherillo F.^b, Squillace A.^b, Viscusi A.^b,
Chirone R.^a, Carrino L.^b

^a*Istituto di Ricerche sulla Combustione (CNR) – P.le V. Tecchio 80, 80125 Napoli, Italy*

^b*Department of Chemical, Materials and Industrial Production Engineering, University of
Naples Federico II, P.le V. Tecchio 80, 80125, Naples, Italy*

Introduction – Metal foams



A **metal foam** is a cellular structure consisting of **solid metal** as well as a large volume fraction of **gas-filled pores**

Properties

- Low specific weight
- High resistance-to-weight ratio
- Good energy absorption
- High stiffness
- High compression strength
- Mechanical damping properties
- Good fire resistance properties
- Thermal and electrical conductivity


Possible applications

Metal foams of different metals are available, such as: aluminum, nickel, magnesium, lead, zinc, copper, bronze, titanium, steel and even gold. The most used in structural applications are **aluminum foams**




Filling of hollow structures

Crashbars



Core of sandwich structures



Manufacturing Techniques

There are two fundamental strategies for making metallic foams


Direct foaming

- melt alloy
- make alloy foamable
- create gas bubbles
- collect foam
- solidify foam

Indirect foaming

- prepare foamable precursor
- remelt precursor
- create foam
- solidify foam

Among the indirect methods, the **powder metallurgy one (PM)**, in which the starting materials are powders, is of particular interest



- **Starting materials** → *metal powder*
blowing agent
 - a. mixing of powders
 - b. compaction of mixture
- **Precursor material** → *foamable metal*
 - c. working and cutting
 - d. foaming
- **Final product** → *metal foam*

TiH_2 is the best blowing agent for aluminum foam because releases the largest amount of hydrogen between 400–600° C, which is a temperature range very close to the melting point of aluminum alloys

PM issues

Commercial foaming precursors are only manufactured in form of extruded rods with rectangular cross section




Alulight® Precursor

- 99.2% aluminium and silicon powders
- 0.8 percent titanium hydride

This **rigid geometry** of the precursor limits the applications of these materials, indeed it is very **difficult if not impossible to make complex shaped foamed components**




Simple Geometries



Coupling Issues



Cold gas dynamic spray (CGDS)



A **powder mixture**, made of the aluminum alloy powders and titanium hydride particles, is **sprayed** on a metal substrate and then the foaming process is carried out in order to obtain the final foamed component.

The shape of the precursor can be ruled by using a **complex shaped** substrate or by imposing a **complex trajectory** at the spraying gun.

- ✓ Low porosity
- ✓ Possibility to spray on thermally sensitive substrates
- ✓ Possibility to produce thick deposits
- ✓ No oxidation
- ✓ No phase change
- ✓ Minimum surface preparation requirements
- ✓ Simple-to-operate equipment
- ✓ No combustion fuels or plasma


Powder Mixing



Classical Mixing techniques

- *Tumbling mixers*
- *Convective mixers*
- *High-shear mixers*

suitable for large, non-cohesive particles (i.e. mean particle sizes greater than 30 μm)




Mixing techniques of fine powders

- *Solvent-based methods*
- *Dry powder methods*
- *Supercritical processing methods*

Alteration of granulometry and nature of powders

Sound Assisted Fluidization

- Does not alter properties and morphology of original particles
- Does not require additional materials
- Easy and cheap to be implemented



In this work

METAL FOAM PRODUCTION BY COLD GAS DYNAMIC SPRAY PROCESS ASSISTED BY FLUIDIZED BED MIXING OF PRECURSORS

□ **Experimental Campaign**


- *Chemico-physical and fluid-dynamic characterization of the aluminum alloy and the blowing agent powders*
- *Mixing of the powders in the sound assisted fluidized bed*
- *Production of the precursor by CGDS and foaming process*

Experimental – Sound assisted fluidized bed


PROCESS PARAMETERS

- Acoustic field intensity : **140 dB**
- Acoustic field frequency: **80 Hz**
- Fluidizing gas: Nitrogen
- Superficial gas velocity: 1.2 cm/s

1. *N₂ cylinder*
2. *Mass flow meter*
3. *Controller*
4. *Pressure transducer*
5. *40mm fluidization column*
6. *Filter*
7. *Microphone*
8. *Sound wave guide*
9. *Wind-box*




Sampling probe




**40mm ID
fluidization column**

Experimental - Materials


AlSi12




- DYMET
- 12% wt Si
- $T_e = 577\text{ }^\circ\text{C}$
- $Density = 2.69\text{ g/cm}^3$
- **Sauter diameter: 41.9 μm**



TiH₂



- DYMET
- Blowing agent
- $T_e = 450\text{ }^\circ\text{C}$
- $Density = 3.75\text{ g/cm}^3$
- **Sauter diameter: 12.9 μm**




By comparison to the Alulight precursor, a mixture richer in blowing agent, to compensate for possible losses during the subsequent deposition process


	AlSi12 %wt	TiH ₂ %wt
Mixture	97.5	2.5

Results – Fluidization tests

AlSi12





TiH₂




Sound application

- Regular pressure drop ($\Delta P/\Delta P_0 \Rightarrow 1$)
- High bed expansion ratios




Results - Mixing

AlSi12 97.5%wt + TiH₂ 2.5%wt



M3000 2070 D8.2 x500 200 um


➤ Titanium hydride (white particles) is well distributed throughout the aluminum-silicon matrix.




Mixed

EDS Analysis

Element	%wt	
Al	81.517	✓
Si	10.717	✓
Ti	7.766	✓




Titanium Ka1




Aluminum Ka1

Results – Mixing tests




Hybrid aggregates



Due to a **break-up and reaggregation mechanism** the mixing process takes place at the **local scale**, namely not only between aggregates made of only one powder but also **inside aggregates**

Mixing degree



The EDS data were elaborated to evaluate the time-dependence of the aggregates mixing degree $M(t)$

Very short times (about 2 min) are needed for aggregates to be efficiently mixed

Experimental - Cold Gas Dynamic Spray (CGDS) apparatus

Low Pressure Cold Spray DYMET 423





Process Parameters

- Carrier Gas: Helium
- Gas pressure: 7 bar
- Gas temperature: 600°C
- Scan rate: 2.5 mm/s
- Stand-off distance: 5 mm
- Feed rate: 3.5 kg/h

The powder mixture was sprayed on a 0.5 mm stainless steel thin plate; in order to achieve a homogeneous material deposition, the mixture was sprayed according to the scheme reported below

CUSTOMIZED PRECURSORS




Results - CGDS


Precursor feature

- Thickness : 5 mm
- Coating volume: about 1600 - 2000 mm³

- Mixture: AlSi12 97.5 + TiH₂ 2.5%wt
- Carrier gas: Helium



SEM of the sample cross section




- Compact and pore free
- Uniform distribution of blowing agent
- Correct proportion between elements

Similar results were obtained using air instead of helium as carrier gas



Results - Foaming

$\Delta s = 8.5 \text{ mm}$





Foaming Parameters

- $T_f = 650 \text{ }^\circ\text{C}$
- $t_f = 9 \text{ min}$



BUBBLES



Conclusions

- ❑ The sound assisted fluidization was proved to be a viable technique to **mix AlSi12 and TiH₂ powders**
- ❑ The CGDS technique allowed to manufacture the precursors for the foaming process. Indeed, **compact precursors** with a **homogeneous dispersion** of TiH₂ powders within the aluminum metal matrix were obtained
- ❑ The foams obtained from the obtained precursors showed a **well developed cellular structure** after the foaming process

Future improvements

- ❑ Refinement of:
 - *The percentage of foaming agent*
 - *The dwell time of the precursor in the oven*
- ❑ Bringing down the manufacturing costs by using a **cheaper process gas** in CGDS (such as air or argon) and **smaller percentage of blowing agent**

AN INNOVATIVE METHOD TO PRODUCE METAL FOAM USING COLD GAS DYNAMIC SPRAY PROCESS ASSISTED BY FLUIDIZED BED MIXING OF PRECURSORS

Ammendola P.^a, Astarita A.^b, Raganati F.^a, Scherillo F.^b, Squillace A.^b, Viscusi A.^b, Chirone R.^a, Carrino L.^b

^a*Istituto di Ricerche sulla Combustione (CNR) – P.le V. Tecchio 80, 80125 Napoli, Italy*

^b*Department of Chemical, Materials and Industrial Production Engineering, University of Naples Federico II, P.le V. Tecchio 80, 80125, Naples, Italy*

*Thanks for
your kind attention*